

Item no.: 376800

## MCE151 - Radio-controlled socket, programmable

from **6,95 EUR**

Item no.: 376800  
shipping weight: 0.30 kg  
Manufacturer: Maclean Brackets



### Product Description

Maclean MCE151 internal radio-controlled socket outlet 1 pc - programmable + battery for remote control devices, which are necessary in today's world where energy saving is a popular topic. The purpose of sockets with remote control is to operate household appliances, e.g. lamps, fans and other electrical devices that we cannot reach to switch on or off. The set is designed for convenience, so you can use the remote control to switch on and off any device connected to the socket, even in the other room or behind the furniture. In addition, sockets allow you to switch off devices that consume energy, even in sleep mode (e.g. electronic devices, household appliances). The controlled socket can even be located behind a wall or glass, the remote control does not need to see the sockets. PROGRAMMING Open the cover of the remote control and insert two 1.5 V AAA batteries. Then press On/Off to check if it works. If the LED on the remote control lights up, the batteries are working properly. Insert the plug into the socket and the LED indicator will start flashing. Enter channel selection mode on the remote control. Note: The socket exits channel selection mode after 29 seconds of inactivity. Press A-On, B-On, C-On or D-On on the remote control to adjust the socket. After a successful connection, the LED display stops flashing. Done - you can now switch the socket on or off by pressing ON/OFF. Deleting an individual channel: Unplug the socket from the wall outlet and plug it back in (in channel selection mode, the LED flashes slowly). Then press and hold the OFF button until the LED starts flashing quickly (approx. 3-4 seconds), indicating that the selected channel has been deleted. After cancelling the channel, the receiver returns to selection mode. The total time to select a channel is 29 seconds. Deleting all selected channels: Remove the plug from the socket and plug it back in (the LED starts flashing slowly in channel selection mode). Then press and hold the OFF button "ALL ON/OFF" until the LED display starts to flash quickly (approx. 3-30 seconds). 4 seconds), which means that all selected ON/OFF channels have been cancelled. The LED will then stop flashing. Technical specifications- Internal remote control socket, 1 piece, programmable + remote control + battery for the - Remote control- Power supply: 230 V, 50 Hz- Maximum load: 16(2)A, 3600W- Operating frequency: 433.92 MHz- Range: approx. 30 m outdoors- Remote control batteries: 2 AAA 1.5 V (included) Set includes- Brand new Maclean MCE151 socket- Remote control for the socket- A set of batteries for the remote control- Original manufacturer's packaging- Proof of purchase

### Specifications

Scan this QR code to  
view the product  
All details, up-to-date  
prices and availability

