





# **RUT950 LTE Router**

Quick start guide v8.0







#### Front view

- LAN Ethernet ports
- WAN Ethernet port
- 3 LAN LEDs
- 4 WAN LED
- 6 Power socket
- 6 Power LED
- Mobile connection status LED
- 8 Mobile signal strength indication LEDs

## Back view

- LTE antenna connectors
- WiFi antenna connectors
- 3 Reset button



Power socket pinout		
No.	Description	Wire color
1	Power	Red
2	Ground	Black
3	-	Green
4	-	White





#### Hardware installation

Remove back panel and insert SIM cards which were given by your ISP (Internet Service Provider).
Correct SIM cards' orientation is shown in the picture below.




2. Attach LTE and WiFi antennas.

- Connect the power adapter to the socket on the front of the device. Then plug the other end of the power adapter into the power socket.
- Connect to the device wirelessly (SSID: Teltonika\_Router) or use Ethernet cable and plug it in to any LAN Ethernet port.

# Configure your computer (Windows)

- Enable the wireless network connection (go to Start > Control Panel > Network and Internet > Network and Sharing Center. In the left panel click Change adapter settings link. Right click on Wireless Network Connection and select Enable).
- Setup wireless network adapter on your computer (right click on Wireless Network Connection and select Properties. After that select Internet Protocol Version 4 (TCP/IP) and click Properties).
- Select Obtain IP address automatically and Obtain DNS server address automatically if they are not selected, Click OK.





 Right click on Wireless Network Connection and select Connect to see available wireless networks.




Choose the wireless network Teltonika\_Router from the list and click Connect.




# Login to device

- 1. To enter routers Web interface type http://192.168.1.1 in your internet browser.
- 2. Use the following parameters when prompted for authentication:



- Configuration Wizard will start after logging in. It is necessary to complete Configuration Wizard to setup router to correct mode. You can leave default settings but it is strongly recommended that you change the password and enable Wireless Security.
- 4. Go to Status > Network information and pay attention to Signal Strength. To maximize the performance try adjusting antennas or changing location of your device to achieve best signal conditions.

### Login to device



#### Safety information

RUT950 router must be used in compliance with any and all applicable national and international laws and with any special restrictions regulating the utilization of the communication module in prescribed applications and environments.

Specifications			
Software	RUT9XX_R_XX.XX.XXX		
Frequency bands*	EEE802.11b/g/n 2400 MHz, GSM/3G/4G, UMTS/HSPA+		
Max. RF power	20 dBm@WiFi, 33 dBm@GSM/GPRS/EDGE, 24 dBm@LTE/WCDMA		
Representative accessories specifications			
Power	AC/DC power adapter 9 V 1 A, 4 pin plug		
GSM/WCDMA/LTE antenna	703-960/1710-1990/2110-2170/2500-2690 MHz, 50 $\Omega$ , VSWR $\leq$ 2, gain** 1 dBi, omnidirectional, SMA male connector		
WiFi antenna	2400-2500 MHz, 50 $\Omega$ , gain** 3dBi, VSWR ≤ 2, omnidirectional, RP-SMA male connector		

<sup>\*</sup> Supported frequency bands are dependent on geographical location and may not be available in all markets.

<sup>\*\*</sup>If an extension cable is used to attach the antenna, the antenna gain may be higher by the amount of cable attenuation. The user is responsible for the compliance with the legal regulations.



This sign on the package means that it is necessary to read the Users Manual before you start using the device.



This sign on the package means that all used electronic and electric equipment should not be mixed with general household waste.



Hereby, Teltonika declares that the radio equipment type RUT950 is in compliance with Directives: 2014/53/EU, 2014/35/EU, 2014/30/EU. The full text of the EU declaration of conformity is available at the following internet address: <a href="http://teltonika.lt/product/rut950/">http://teltonika.lt/product/rut950/</a>

www.teltonika.lt ©2018 Teltonika